



NACHO CHEESE INSTRUCTIONS

A large bag of cheese has
approximately 27 3-oz serving.

WARNING! Cheese and unit can get HOT!

1. Attach cheese dispenser hose to the cheese bag.
2. Open door to warmer and lay bag into the lower storage opening with the hose facing down.
3. Turn knob to OPEN the tube regulator.
4. Insert cheese tube in the "S" section and turn knob to CLOSE the regulator with the cheese tube barely sticking out of the bottom.

NOTE : You may place a 2nd bag of cheese in the reservoir section of the unit to keep warm.

5. Close door and plug in the unit. *Do not use a cord!*
6. There are THREE buttons on the machine. Continuous – Pre measured – Manual to dispense the cheese
7. Any un-used cheese can be store in the refrigerator and reused the next day. Yum!
8. You may put the bag of cheese in the microwave and heat on LOW to warm it up prior to putting it in the unit.

CLEANING:

DO NOT TAKE UNIT APART.....just wipe off the machine using warm water and a soft rag....DO NOT SUBMERSE IN WATER!